

Sage Decal Application & Care

This guide provides clear instructions on how to properly apply Sage decals for optimal adhesion, followed by best practices for maintaining their appearance and durability over time.

Decal Application Instructions

- Decals are best applied to flat, smooth surfaces such as eggshell-to-semi-gloss painted walls, sealed MDF, metal, or glass. Avoid textured, porous, or glossy finishes (like silicone or Teflon coatings), as they may cause the edges to lift over time.
- If applying to freshly painted surfaces, allow proper curing time (typically 14 days for standard latex paint and up to 30 days for low VOC or stain blocking paints) to ensure secure bonding.
- Apply only when both the wall surface and decal material are between 60–100°F (1638°C), and relative humidity is below 70%.

Surface Prep:

1. Clean the application area with warm water and a mild dish soap. Rinse thoroughly and dry completely before proceeding.
2. Wipe the surface twice with a 70% isopropyl alcohol / 30% water solution. Allow to dry.



Note: It is recommended to avoid ammonia-based glass cleaners or silicone polishes, as their residues can interfere with adhesion and may damage the decal.

Post-installation Care:

Wait at least 24 hours (72 hours preferred) before wet cleaning or disinfecting.

Decal Care

Our decals are crafted using high-quality acrylic base material and are protected by a durable laminate film that resists scratches, dirt, and sunlight. They're resilient against hot water and most common cleaning agents.

Cleaning Recommendations:

- Use standard soap and water with a nonabrasive cloth.
- You can safely use common disinfectants like hydrogen peroxide (less than 1.5%) or products that contain quaternary ammonium.
- For a deeper clean, a diluted bleach solution (less than 0.5%) may be used, ensure the area is thoroughly rinsed with clean water afterward to eliminate any remaining residue.

What to Avoid:

Avoid strong cleaning chemicals such as concentrated alcohols (isopropanol or ethanol), ammonia, phenolics, strong alkalis, citrus-based cleaners, steam, or ketone solvents. These substances may cause fading, warping, or the adhesive to weaken over time.



Need Replacement Decals?

Visit the Sage Support site and search for the **Hardware Order Form** to order additional buttons and accessories or follow the QR code given to the left for the form.